

English

Installation

- Mount the shredder securely to the rim of the waste basket
- Connect the power cord to any standard 230 V AC, 50 Hz outlet

Operation

The switch located on housing top enables you to select one of the followings settings:

- **auto** with this setting the shredder is automatically started by inserting paper into the shred opening
- **rev** in the unlikely event of paper jam, the reverse setting can be used to help clear the cutters of paper that has not passed through properly
- **off** this setting turns off all functions of the shredder

Capacity

Continuous shredding should not last more than 2 minutes, after which the shredder should be allowed to cool down for 60 minutes before continuing. In the event of a paper jam, or if the shredder is used continuously for more than 2 minutes, the shredder will automatically switch itself off. In case of an overload, set the switch in the "off" position for 15 seconds before turning the device back on.

Warning

- Do not place fingers too close to the feed slot as serious injury may occur
- Always switch-off the device before removing it from the waste basket
- Always disconnect the power plug before opening the case, cleaning, moving, or emptying the waste basket
- Repairs must be executed by a specialist
- Keep the waste basket emptied so that the shredder output is not impeded.
- The unit should only be fed with paper (except mentioned differently on packaging and machine)
- Keep all loose articles of clothing, ties, jewelry, long hair or other loose objects away from opening
- Keep children away from the machine

Français

Installation

- Fixer solidement le destructeur de documents sur le bord du réceptacle
- Brancher le cordon d'alimentation secteur sur une prise standard 230 Vca (50 Hz)

Fonctionnement

Le commutateur en face supérieure permet de sélectionner l'un des modes suivants:

- **auto** le destructeur de documents se met automatiquement en marche lorsque l'on y introduit une feuille de papier
- **rev** Dans le cas improbable d'un blocage du papier, ce mode permet de débloquer les couteaux
- **off** Coupe l'ensemble des fonctions du destructeur de documents

Capacité

Ne pas dépasser une durée de destruction de 2 minutes, au bout de laquelle il convient de laisser refroidir l'appareil pendant 60 minutes avant de continuer. En cas de blocage papier ou de destruction en continu pendant plus de 2 minutes, l'appareil se met automatiquement hors tension. En cas de sur charge, mettre le commutateur en position "off" et attendre 15 secondes avant de remettre l'appareil sous tension.

Mise en garde

- Ne pas approcher les doigts de la fente d'alimentation : risque de blessures graves
- Toujours mettre l'appareil hors tension avant de le désolidariser du réceptacle
- Toujours débrancher le cordon d'alimentation secteur avant d'ouvrir le boîtier, de nettoyer ou de déplacer l'appareil, ou de vider le réceptacle
- Toutes les réparations doivent être confiées à un spécialiste
- Vider régulièrement le réceptacle de manière à éviter tout engorgement de l'appareil
- L'appareil est exclusivement destiné au déchiquetage du papier (sauf mention contraire sur l'emballage ou l'appareil)
- Veiller à ne pas laisser prendre dans l'ouverture les vêtements, cravates, bijoux, cheveux etc
- Tenir les enfants à l'écart de l'appareil